



HS2100 / HS3100



EMC Configuration and Accessories Guide

*Designed to assist customers and partners with model and
configuration guidance*

HS2100 / HS3100 Configuration Matrix

CONFIGURATION OPTIONS:	DESCRIPTION
HS2100-OTH	HS2100 Rugged Wired Headset Over-The-Head Headband Includes HS2100 Boom Module and HSX100 OTH Headband Module
HS2100-BTN-L	HS2100 Rugged Wired Headset Behind-The-Neck Headband Left Includes HS2100 Boom Module and HSX100 OTH Headband Module
HS3100-OTH	HS3100 Rugged Bluetooth Headset Over-The-Head Headband Includes HS3100 Boom Module and HSX100 OTH Headband Module
HS3100-BTN-L	HS3100 Rugged Bluetooth Headset Behind-The-Neck Headband Left Includes HS3100 Boom Module and HSX100 BTN Left Headband Module
HS3100-OTH-SB	HS3100 rugged Bluetooth headset with over-the-head headband includes HS3100 shortened boom module and HSX100 over-the-head headband module
HS3100-BTN-LSB	HS3100 rugged Bluetooth headset with behind-the-neck headband left includes HS3100 shortened boom module and HSX100 behind-the-neck headband left module.

Headset Models



HS2100 Corded Headset



(Short Boom)

HS3100 Bluetooth Headset

HS2100 / HS3100

- HD Voice Brings Incredible Audio Clarity to cordless and corded models
- Built to handle the everyday inevitable drops
- Dust-proof, Spray-proof and Waterproof
- Ready for the Freezer and Outdoor Subzero Temperatures (Recommend Shortened Boom variant)
- Feather-light for extraordinary comfort
- Noise cancellation for a superior voice experience in the noisiest environments
- Swap batteries on the fly — without losing the Bluetooth connection
- Customizable wearing styles
- Split-second tap-to-pair simplicity
- Detachable swivel boom minimizes costs
- User-replaceable ear pads and mic windscreens maximize comfort and hygiene
- 15 hours of battery power for cordless models
- Microphone Mute

HS2100 HS3100 Accessories Guide



HS2100 / HS3100 Modules

Boom Modules



Boom + Battery + Windscreen

HS3100-BOOM-01*

HS3100 Boom Module Includes microphone boom, battery, and Windscreen



HS3100-SBOOM-01

HS3100 Shortened Boom Module Includes microphone boom, battery, and Windscreen



Boom + Windscreen

HS2100-BOOM-01*

HS2100 Boom Module Includes microphone boom and Windscreen

Headband Modules



HSX100-OTH-HB-01

HS2100 and HS3100 Over-The-Head headband including Foam Pad, T-Bar with pad. Does not include Boom Module.

HS3100 8 Slot Battery Toaster



SAC-HS3100-B8-01

Includes: HS3100 8-slot Battery Charger

Requires: Level VI Power Supply PWR-BGA12V50W0WW, DC Line Cord CBL-DC-388A1-01, and country specific line cord

Additional Accessories for Battery Toaster



PWR-BGA12V50W0WW

Level VI AC/DC Power Supply (Brick, replacement for PWRS-14000-148R)

AC Input: 100-240V, 2.4A

DC Output: 12V, 4.16A, 50W

Requires: DC line cord and Country specific grounded AC line cord.



CBL-DC-388A1-01

DC Line Cord for running the single slot cradles or battery chargers from a single Level VI power supply PWR-BGA12V50W0WW, Level VI replacement for PWRS-14000-148R.



23844-00-00R

US AC line cord, 7.5 feet long, grounded, three wire for power supplies.

HS3100 Battery

Spare Battery



BTRY-HS3100-HS1-01

Single HS3100 Battery

HS2100 Cables

Headset Adapter Cables



25-114186-03R*

WT41N0 headset adapter cable with a coiled section, Requires CBL-HS2100-QDC1-01 to connect to HS2100 headset



25-124411-03R*

MC31 / MC32 headset adapter cable, Requires CBL-HS2100-QDC1-01 to connect to HS2100 headset



CBL-HS2100-3MS1-01

HS2100 headset standard cable to use with TC5X, TC7X or TC8000. Requires 3.5mm keyed / collared female to 3.5mm male headset adapter cable (CBL-TC51-HDST35-01).



CBL-HS2100-12S1-01

HS2100 cable to connect directly to WT6000 ONLY

HS2100 / HS3100 Consumables

Consumables



KT-HSX100-EPL1-20

HSX100 Headset Leatherette
Ear Pad, Pack of 20



KT-HSX100-EPF1-20

HSX100 Headset Foam
Ear Pad, Pack of 20



KT-HSX100-SMC1-50

HSX100 Silicone Mic
Cover for use in Freezer
environment, Pack of 50



KT-HSX100-MWS1-50

HSX100 Headset Series
Microphone Windscreen,
Pack of 50